

AP00.20-U-1208VAB SERVICE SHEET for Mercedes-Benz Maintenance System (USA)

MODEL 171

AMG models only

Passenger cars Model Year 2006

USA



Customer:		Repair order number:		
First visit	at 1,000 - 3,000 miles	Performed	YES NO	
Tire Rotation (non staggered width wheel setup only)	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES NO	
Tire Inspection (staggered and non- staggered width wheel setup)	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES NO	
Current mileage reading: Additional notes:		Oil grade/viscosit	y:	
Service work to be performe service advisor:	ed as advised by Completion date:	Confirm wo below:	rk has been performed by signing	

i

US Service 4 through US Service 20 apply to "Additional work" items only.

Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2. Perform each service as described.

US Service 1		first at 10,000 mi or 1 year;	after first every 20,000 mi or 2 years	
I	US Service 2	first at 20,000 mi or 2 years;	after first every 20,000 mi or 2 years Not OK	
\downarrow	Ļ		\downarrow	
	Fod	Engine compartment		
	0	Leakage - Major components Check for chafe marks, line routing, dama- ged components in the event of leakage, determine cau- se and perform repair via separate work or- der		AP00.20-P-0053V
	0	Check catch, safety catch and hinges on en- gine hood for proper operation.		AP88.40-P-8851V
	0	Check battery condition using "Midtronics MCR 717" Tester		AP54.10-U-5453A
	0	Check condition of poly-V-belt		AP13.22-P-1351VT
		Check fluid level, correct as required i If there is a loss of fluid, determine cau- se and perform repair via separate work or- der		
	0	Brake system		AP42.10-P-4210V
	0	Power steering		AP46.00-P-4611V
	0	Windshield washer system (incl. summer/winter cleanser)		AP82.35-P-8210N
600		Interior		
	0	Reset service indicator in instrument cluster Function check		AP00.20-P-0042V
	0	Horn, warning/indicator lamps, illumina- tion and interior lighting		
	0	Windshield wipers, windshield washer sy- stem		AP82.30-P-8252V
	0	Headlamp cleaning system		
	0	Check seat belts and buckles for signs of ex- ternal damage and proper function		AP91.40-P-9150V
	0	Check parking brake (function test only)		AP42.00-P-4290V
eț C		Wheels, brakes		
•	• 0	Remove and install wheels		AP40.10-P-4050V
		Check brake pads for lining thickness (remove 1 front wheel)		AP42.10-P-4251V
	0	Check front/rear brake pads for lining thickness		AP42.10-P-4251V
	0	Check condition/thickness of front/rear brake discs		AP42.10-P-4251V
	0	re tread depth, record in mm: LF RF LR RR outside center		AP40.10-P-4051Z
		inside		

Service 1	2		Not OK	
↓ 	Ļ		Ļ	
		Underside of vehicle		
† ' †	0	Leakage - Major components Check for chafe marks, line routing, dama- ged components [1]In the event of leakage, determine cau- se and perform repair via separate work or- der		AP00.20-P-0053V
	0	Check front axle ball joints for play, check rubber boots		AP33.20-P-3353V
	0	Inspect condition of flexible discs		AP41.10-P-4152V
	0	Inspect play of tie rod and and drag link joints, inspect rubber boots		AP46.00-P-4653V
6000	•	Trunk		
	Ο	Check trunk lighting		
	j	Vehicle front/rear		
	Ο	Check wiper blade condition		AP82.30-P-8253G
	Ο	Check and correct headlamp setting		AP82.10-P-8260V
Complete	d⊠ ↓		Not OK ↓	
US Service 3		every 10,000 mi or 1 year:		
		Engine compartment		
		Engine - oil and filter change		AP18.00-P-0101VT
US Service 4		every 2 years:		
		Check bodywork for paint work damage by service advisor		AP98.00-P-9850BA
		Underside of vehicle		
		Chassis and load-bearing body compo- nents: Check for damage and corrosion by service advisor		AP00.20-P-0090BA
		Engine compartment		
		Replace brake fluid		
US Service 5	_	every 30,000 mi or 2 years:		
		Passenger compartment		
		Replace combination filter		AP83.00-P-8384V
US Service 6 and	7	not applicable		
US Service 8		every 40,000 mi or 4 years:		
		Engine compartment		
		Replace engine air-cleaner insert		AP09.10-P-0980VT
US Service 9 and 10		not applicable		
US Service 11		every 60,000 mi or 5 years:		
		Trunk		
		Replace fuel filter		AP47.20-P-0780Q

Comple				Not OK	
US Service 1	↓ 2	every 100,000 mi or 5 years:		Ļ	
	-	Engine compartment			
		Replace spark plugs			AP15.10-P-1580VT
US Service 1		every 150,000 mi or 15 years:			
ob bei vice i	-	Engine compartment			
		Replace coolant			AP20.00-P-2080VT
US Service 14-		not applicable			
US Service 2	0	once at 40,000 mi			
		Underside of vehicle			
		Automatic transmission - oil and filter			AP27.00-P-2702W
		change			
Complete		Perform:	Yes	Not OK	
	Ļ	Vehicle over 150,000 mi:	↓	\downarrow	
		Check if all fluid levels and changes are up-			
		dated			
₩ AP		Transmission			
₩ĨAP		Rear axle			
		Check if air, fuel, ventilation filters are up- dated			
₩AP		Engine air filter			
₩AP		Fuel filter			
₩AP		Combination filter			
		Check integrity of engine, mechanical co- monents			
₩ AP		Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ			
₩ĨAP		Perform leak down test (hot and cold)			AP00.20-P-0053V
₩ AP		Check spark plugs			
₩ AP		Exhaust system hangers and leaks			
		Check damaged / worn drivetrain parts			
₩AP		Front wheel bearing play			
₩ AP		Rear wheel bearing play			
₩AP		Axle joint play			
₩ĨAP		Flexible disks			
₩ĨAP		Tie rod and drag link joints			