Mercedes-Benz

AP00.20-U-1208BB

SERVICE SHEET for Mercedes-Benz Maintenance System (USA)

MODEL 209

except AMG models

Passenger cars Model Year 2006

USA



Customer:			Repair order number:			
First visit	at 1,000 - 3,000 miles		Performed	YES NO		
Tire Rotation (non staggered width wheel setup only)	Performed in accordance with the tire manufacturer's recommended intervals		Tires rotated	YES NO		
Tire Inspection (staggered and non- staggered width wheel setup)	Inspect tires for damage and correct tire inflation pressure		Tires inspecte	d YES NO		
Current mileage reading:			Oil grade/viso	osity:		
Additional notes:						
Service work to be performed service advisor:	l as advised by	Completion date:	Confirm below:	work has been performed by signing		
1st A service at 13,000 miles o 1st B service at 26,000 miles o						
Determine "Additional Work" (check if applicable)	" needed, if any. Refer to "/	Additional work" sec	tion			
once at first service at:	13,000 mi or 1 year		every:	2 years		
at approx. every:	52,000 mi or 4 years			5 years		
	52,000 mi or 5 years		once at:	39,000 mi		
	65,000 mi or 5 years			143,000 mi		
	78,000 mi or 5 years					
	91,000 mi or 5 years					
	143,000 mi or 15 years					

i See last page for "Additional Work".

Additional flat rates apply for procedures marked with FAP

Completed 🖂		A-Service	O B-Service	Not OK	
↓ ↓		Ļ	Ŷ	Ļ	
	Interior				
	Reset maintenance counter in instrument cluster	\boxtimes	\otimes		
	Function check				
	Horn, high beam flasher, hazard warning flasher, turn signals	\boxtimes	\otimes		
	Warning/indicator lamps, illumination and interior lighting	\boxtimes	\otimes		
	Windshield wipers, windshield washer system	\boxtimes	\otimes		AP82.30-P-8252A
	Headlamp cleaning system	X	\otimes		
	Front and rear lamps	X	\otimes		
	Check seat belts for damage and proper function		\otimes		AP91.40-P-9150P
	Check parking brake (function test only)		\otimes		AP42.00-P-4290BA
	Wheels, brakes				
	Remove and mount wheels		\otimes		AP40.10-P-4050Z
	Check front brake pads for lining thickness (remove one front wheel)	\boxtimes			AP42.10-P-4251BQ
	Check brake pads for lining thickness front/rear		\otimes		AP42.10-P-4251BQ
	Check condition/thickness of brake discs front/rear		\otimes		AP42.10-P-4251BQ
	Inspect tires for damage and condition	\boxtimes	\otimes		AP40.10-P-4051Z
	Measure tread depth, enter in mm: LF RF LR RR		\otimes		AP40.10-P-4051Z
	outside center inside				
	Correct tire inflation pressure	X	\otimes		
	Underside of vehicle				
	Leakage - Major components Check for chafe marks, line routing, dama- ged components 1 In the event of leakage, determine cau- se and perform repair via separate work or- der		8		AP00.20-P-0053BA
	Check condition of front axle ball joints and rubber boots		\otimes		AP33.20-P-3353BP
	Check condition of steering mechanical components and rubber boots		\otimes		AP46.00-P-4653F

Completed	۲ ا		A-Service □	O B-Service	Not OK ↓	
	•	Engine compartment	•		•	
		Leakage - Major components Check for chafe marks, line routing, dama- ged components i In the event of leakage, determine cau- se and perform repair via separate work or- der		8		AP00.20-P-0053BA
		Check condition of poly-V-belt		\otimes		
		Engine 113 Engine 272				AP13.22-P-1351Z AP13.22-P-1351PIT
[Check catch, safety catch and hinges on en- gine hood for proper operation.	\boxtimes	\otimes		
		Replace dust filter Engine oil and filter change	X	\otimes		AP83.00-P-8381P
	_	Engine 113		~		AP18.00-P-0101AF
		Engine 272 Check fluid level, correct as required ilf there is a loss of fluid, determine cau- se and perform repair via separate work or- der				AP18.00-P-0101PIT
		Brake system	X	\otimes		AP42.10-P-4210Z
C		Power steering		\otimes		AP46.00-P-4611P
		Windshield washer system (incl. summer/winter cleanser)	\boxtimes	\otimes		AP82.35-P-8210P
[[Battery, check and correct fluid level; check battery condition using "Midtronics MCR 717" Tester	\boxtimes	\otimes		AP54.10-U-5453A
iosi		Vehicle front/rear				
		Check and correct headlamp setting		\otimes		AP82.10-P-8260P
C		Check wiper blade condition	\mathbf{X}	\otimes		AP82.30-P-8253G
		Trunk				
		Correct tire inflation pressure in spare tire	\boxtimes	\otimes		
C		Check trunk lighting	\boxtimes	\otimes		
		Additional Work				
Completed	1 X	Perform:	Yes ↓		Not OK ↓	
	¥	Once at first service at 13,000 mi or 1 year:	v		¥	
iar [Parking brake - Adjust cable slack				AP42.20-P-4262P
		Once at 39,000 mi:				
₩AP [Automatic transmission - oil and filter change				AP27.00-P-2702W
		At approx. every 52,000 mi or 4 years:				
₩ ² AP [Check condition of driveshaft flex discs				AP41.10-P-4152Z
₩ AP [Replace air cleaner filter element				
i≆ap [At approx. every 52,000 mi or 5 years: Replace activated charcoal filter (if equip- ped)				AP83.00-P-8382P

	Completed 🗵	Perfo		Not OK	
	\downarrow	At approx. every 65,000 mi or 5 years:	↓	Ļ	
₩ ° AP		Replace fuel filter			
		At approx. every 78,000 mi or 5 years:			
₩ AP		Replace spark plugs (engine 272)			AP15.10-P-1580PIT
		At approx. every 91,000 mi or 5 years:			
₩ ° AP		Replace spark plugs (engine 113)			AP15.10-P-1580A
		At approx. every 143,000 mi or 15 years			
🖙 AP		Replace coolant			
		(water/anticorrosion/antifreeze mixtur	e)		
		Engine 113:			AP20.00-P-2080A
		Engine 272:			AP20.00-P-2080PIT
		Every 2 years:			
₩ AP		Replace brake fluid			AP42.00-P-4280BP
₩ AP		Check body paint damage by service advisor			AP98.00-P-9850BA
₩ ° AP		Check chassis and supporting body part	s 🗆	П	AP00.20-P-0090BA
		for damage and corrosion	, <u> </u>		A 00.201 00000A
		by service advisor			
		Every 5 years:			
₩Â₽		Tilt/sliding roof: clean sliding rails and s ders	ili-		AP77.20-P-7731A
		Vehicle over 143,000 mi:			
		Check if all fluid levels and changes are dated	up-		
₩Â₽		Transmission			
₩ AP		Rear axle			
		Check if air, fuel, ventilation filters are dated	up-		
₩ AP		Engine air filter			
₩ AP		Fuel filter			
₩ AP		Dust filter			
₩Â₽		Activated charcoal filter (if equipped)			
		Check integrity of engine, mechanical c monents	0-		
₩		Perform compression test (hot and cold Refer to BE01.00-Z-9999AZ) 🗆		
⊯≊AP		Perform leak down test (hot and cold)			AP00.20-P-0053BA
⊯ ≊AP		Check spark plugs			
⊯≊AP		Exhaust system hangers and leaks			
		Check damaged / worn drivetrain parts			
₩ AP		Front wheel bearing play			
₩ AP		Rear wheel bearing play			
₩ AP		Axles joint play			
₩ AP		Flexible discs			
₩ AP		Tie rod and drag link joints			