Service

AP00.20-U-1208D

Service Sheet for Mercedes-Benz Maintenance System (USA)

17.06.04

MODEL 211 except AMG models

Passenger Cars Model Year 2005

USA



| Customer: | | Repair order numbe | er: | |
|---|--|----------------------|---------------------|-----------------|
| First visit | at 1,000 - 3,000 miles | Performed | YES | NO |
| Tire Rotation (non-staggered width wheel setup only) | Performed in accordance with the tire manufacturer's recommended intervals | Tires rotated | YES | NO |
| Tire Inspection (staggered and non- staggered width wheel setup) | Inspect tires for damage and correct tire inflation pressure | Tires inspected | YES | NO |
| Current mileage reading: | | Oil grade/viscosity: | | |
| Additional notes: | | | | |
| | | | | |
| Service work to be performed service advisor: | d as advised by Completion da | | onfirm work has bee | en performed by |
| | | | | |

i

US Service1 through US Service 11 apply to "Additional work" items only.

Vehicle determines need for US Service 12 (Engine oil and filter change) as well as US Service 13 or US Service 14 (formerly A-Service and B-Service respectively).

Perform service necessary as indicated in display of instrument cluster only.

Perform each service as described.

| completed | $\downarrow \\$ | | | Not O.F | c . |
|-----------------------------|-----------------|--|-----------------------------|---------|------------------|
| US Service 1 | | Display in instrument cluster | | | |
| | | Wheels, brakes | | | |
| | | Check brake pads for lining thickness f check condition of brake discs front/rea | | | AP42.10-P-4251R |
| US Service 2 | | every 52,000 mi or 4 years: | | | |
| | | Engine compartment | | | |
| | | Replace engine air-cleaner insert | | | |
| US Service 3 | | every 26,000 mi or 2 years: | | | |
| | | Engine compartment | | | |
| | | Replace combination filter | Models E320, E320 CDI, E500 | | AP83.00-P-8384T |
| US Service 4 | | every 26,000 mi or 2 years: | | | |
| | | Engine compartment | | | |
| | | Replace dust filter | Models E320 CDI, E500 | | AP83.00-P-8381T |
| US Service 5 | | every 65,000 mi or 5 years: | | | |
| Gasoline engines (112, 113) | | Engine compartment | | | |
| | | Replace fuel filter | | | AP47.20-P-0780TC |
| US Service 5 Diesel engine | | every 26,000 mi or 2 years: | | | |
| (648) | | Engine compartment | | | |
| | | Replace fuel filter | | | AP47.20-P-0780T |
| US Service 6 | | every 52,000 mi or 5 years: | | | |
| | | Interior | | | |
| | | Replace activated charcoal filter | Models E320 CDI, E500 | | AP83.00-P-8382F |
| US Service 7 | | every 91,000 mi or 5 years: | | | |
| | | Engine compartment | | | |
| | | Replace spark plugs | Engines 112, 113 | | AP15.10-P-1580AB |

| completed | \downarrow | | | Not O.F | ζ. |
|---------------|--------------|---|-----------------------------------|-----------------|------------------|
| US Service 8 | | every 143,000 mi or 15 years: | | | |
| | | Engine compartment | | | |
| | | Replace coolant | Gasoline engines | | AP20.00-P-2080DA |
| | | | Diesel engines | | AP20.00-P-2080BA |
| US Service 9 | | every 2 years: | | | |
| | | Check bodywork for paintwork damag by service advisor | е | | AP98.00-P-9850BA |
| | | Underside of vehicle | | | |
| | | Chassis and load-bearing body components: Check for damage and corrosion by service advisor | | | AP00.20-P-0090BA |
| | | Engine compartment | | | |
| | | Replace brake fluid Prior to replacing brake fluid perfor via STAR DIAGNOSIS SYSTEM (\$1 - Check pretension pressure of SControl (SBC) pressure reserved 2 - Check operating time of Sensor (SBC) unit | SDS): Sensotronic Brake sir | | AP42.00-P-4281T |
| US Service 10 | | every 5 years: | | | |
| | | Interior | | | |
| | | Tilt/sliding roof: Clean slide rails and slide shoes | | AP77.20-P-7731A | |
| US Service 11 | | every 3 years: | | | |
| | | Interior | | | |
| | | Panorama sliding roof: Clean and lubr mechanism | icate guide | | AP77.20-P-7732PB |
| US Service 12 | | every 13,000 mi or 1 year: | | | |
| | | Engine compartment | | | |
| | | Engine - oil and filter change | Engine 112 | | AP18.00-P-0101AE |
| | | | Engine 113 | | AP18.00-P-0101AF |
| | | | Engine 648 | | AP18.00-P-0101TC |

| US Service 13 | | first at 13,000 mi or 1 year; after first every 26,000 mi or 2 years | | | |
|------------------|------------------|---|----------------------|----------|------------------|
| | JS Service 14 | first at 26,000 mi or 2 years; after first every 26,000 mi or 2 years | | Not O.K. | |
| 1 | 1 4 | | | 1 | |
| | 3 | Engine compartment | | | |
| | 0 | Leakage - Major components Check for chafe marks, line routing, damaged components I In the event of leakage, determine cause and perform repair via separate work order | | | AP00.20-P-0053BA |
| | 0 | Check auxiliary battery (12ah) (located underneath A/C combination/dust filter, R/H rear side of engine compartment) condition using "Midtronics MCR 717" Tester | | | AP54.10-U-5453A |
| | 0 | Inspect poly-V-belt for damage | | | AP13.22-P-1351Z |
| | 0 | Check catch, safety catch and hinges of engine hood for proper operation. Replace components with even the slightest malfunction. | | | AP88.40-P-8851T |
| | | Check and correct fluid level I If there is a loss of fluid, determine cause and perform repair via separate work order | | | |
| | 0 | Brake system | | | AP42.10-P-4210Z |
| | 0 | Power steering | Gasoline Engines | | AP46.00-P-4611BB |
| | | | Diesel Engines | | AP46.00-P-4611P |
| | 0 | Engine cooling system, antifreeze and corrosion protection | | | AP20.00-P-2010Z |
| | 0 | Windshield wipers, washer system (incl. summer/winter cleanser) | | | AP82.35-P-8210N |
| | | Interior | | | |
| | 0 | Reset service indicator in instrument cluster | Vehicles up to 09/03 | | AP00.20-P-0042T |
| | | | Vehicles as of 10/03 | | AP00.20-P-0042TA |
| | | Function check | | | |
| | 0 | Warning/indicator lamps, illumination and interior lighting | | | |
| | 0 | Windshield washer system, incl. rear window washer (where applicable) | | | AP82.30-P-8252T |
| | 0 | Headlamp cleaning system | | | |
| | 0 | Check seat belts and buckles for signs of external damage and proper function | | | AP91.40-P-9150M |

| US Service | US Service | • | Not O.k | (|
|------------|------------|---|---------|------------------|
| 13 I | 14 | | I | |
| <u> </u> | <u> </u> | | * | |
| | 0 | Check Sensotronic Brake Control (SBC) hydraulic unit | | AP42.50-P-4259A |
| | 0 | Check parking brake (function test only) | | AP42.00-P-4290R |
| | | Wheels, brakes | | |
| | 0 | Inspect tires for damage and splits, measure tread depth, enter in mm: LF RF LR RR outside | | AP40.10-P-4051Z |
| | 0 | Check thickness of front brake pads (remove 1 front wheel at Service 13) Check thickness of front/rear brake pads (required at Service 14) | | AP42.10-P-4251R |
| | 0 | Correct tire inflation pressure (incl. spare tire) | | |
| | | Underside of vehicle | | |
| | 0 | Leakage - Major components Check for chafe marks, line routing, damaged components i In the event of leakage, determine cause and perform repair via separate work order | | AP00.20-P-0053BA |
| | 0 | Check front axle joints for play, check rubber boots | | AP33.20-P-3353BA |
| | 0 | Inspect condition of flexible discs | | AP41.10-P-4152Z |
| | 0 | Inspect play of tie rod and drag link joints, inspect rubber boots | | AP46.00-P-4653F |
| | | Trunk | | |
| | 0 | Check main battery condition using "Midtronics MCR 717" Tester | | AP54.10-U-5453A |

| | completed | ¥ | Perform: | Yes ↓ | Not O.K. ↓ |
|-------------------|-----------|---|---|----------|--------------------|
| | | | Vehicle over 143,000 mi: | | |
| | | | Check if all fluid levels and changes are updated | | |
| [#F / | AP | | Transmission | | |
| [#F / | AP | | Rear axle | | |
| [#F / | AP | | Front axle (if applicable) | | |
| [#F / | AP | | Transfer case (if applicable) | | |
| | | | Check if air, fuel, ventilation filters are updated | | |
| [# / | AP | | Engine air filter | | |
| (≆° A | AP | | Fuel filter | | |
| [#F / | AP | | Combination / dust filter (if applicable) | | |
| [=] | AP | | Activated charcoal filter (if applicable) | | |
| | | | Check integrity of engine, mechanical components | | |
| [#F # | AP | | Perform compression test (hot and cold) | | ☐ BE01.00-Z-9999AZ |
| i≆ A | AP | | Perform leak down test (hot and cold) | | ☐ AP00.20-P-0053BA |
| [#F / | AP | | Check spark plugs | | |
| [#F / | AP | | Exhaust system hangers and leaks | | |
| | | | Check damaged / worn drivetrain parts | | |
| FF A | AP | | Front wheel bearings play | | |
| [#F / | AP | | Rear wheel bearings play | | |
| [#F / | AP | | Axles joints play | | |
| [4] | AP | | Flexible discs | | |
| [4 5 / | AP | | Tie rod and drag link joints | | |