

AP00.20-U-1208R	SERVICE SHEET for Mercedes-Benz Maintenance System (USA)	1.3.05
-----------------	--	--------

MODEL 251

Light Truck Model Year 2006



Customer:		Repair order number:		
First visit	at 1,000 - 3,000 miles	Performed	YES NO	
Tire Rotation	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES NO	
Tire Inspection	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES NO	
Current mileage reading:		Oil grade/viscosity:		
Service work to be performed as advised by service advisor: Completion date: Confirm work has been performed by signing below:				

i

US Service 4 through US Service 20 apply to "Additional work" items only.

Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2

Perform each service as described.

US Service		first at 13,000 mi or 1 year;	after first every 26,000 mi or 2 years	
1	US Service	first at 26 000 mi or 2 years	after first every 26,000 mi or 2 years	
	2	instat 20,000 ini di 2 years,	Not OK	
1	↓		\	
6		Interior		
	0	Reset service indicator in instrument cluster		AP00.20-P-0042RT
		Function test		
	0	Battery, check battery condition using "Midtronics MCR 717" tester		AP54.10-U-5453A
	0	Check parking brake (function test only)		AP42.00-P-4290RT
	0	Horn, warning/indicator lamps, illumination and interior lighting		
	0	Windshield wipers, windshield washer system		AP82.30-P-8252RT
	0	Headlamp cleaning system, where applicable		
	0	Check seat belts and buckles for signs of external damage and proper function		AP91.40-P-9150RT
		Wheels, brakes		
	0	Inspect tires for damage and splits, measure tread depth, record in mm: LF RF LR RR		AP40.10-P-4051RT
		center inside		
	0	Remove and fit wheels		AP40.10-P-4050RT
		Check front brake pads for lining thickness, remove 1 front wheel		AP42.10-P-4251RT
	0	Check front/rear brake pads for lining thickness		AP42.10-P-4251RT
	0	Check condition/thickness of front/rear brake discs		AP42.10-P-4251RT
	0	Correct tire inflation pressure		
		Underside of vehicle		
·	. 0	Leakage - Major components Check for chafe marks, line routing, dama-		AP00.20-P-0053RT
		ged components i In the event of leakage, determine cause and perform repair via separate work order		
	0	Check front axle ball joints for play, check rubber boots		AP33.20-P-3353RT
	0	Check rear axle ball joints for play, check rubber boots		AP35.20-P-3555RT
	0	Inspect play of tie rod and and drag link joints, inspect rubber boots		AP46.00-P-4653RT
	0	Inspect condition of flexible discs		

Service 1		2			Not OK	
1		\downarrow			↓	
ioE)	Vehicle front/rear			
		0	Check wiper blade condition			AP82.30-P-8253G
		0	Check and correct headlamp setting			AP82.10-P-8260RT
		ı	Engine compartment			
		0	Leakage - Major components Check for chafe marks, line routing, damaged components in the event of leakage, determine cause and perform repair via separate work order			AP00.20-P-0053RT
		0	Check catch, safety catch and hinges on engine hood for proper operation.			AP88.40-P-8851RT
		0	Check condition of poly-V-belt			
			Engine 113:			AP13.22-P-1351RT
			Engine 272:			AP13.22-P-1351RTC
			Check fluid level, correct as required i If there is a loss of fluid, determine cause and perform repair via separate work order			
		0	Brake system			AP42.10-P-4210RT
		0	Power steering			AP46.00-P-4611RT
		0	Windshield washer system (incl. summer/winter cleanser)			AP82.35-P-8210RT
			Additional Work			
(Completed	d ⊠ ↓			Not OK ↓	
US S	Service 3		every 13,000 mi or 1 year:			
			Engine compartment			
			Engine - oil and filter change	Engine 113:		AP18.00-P-0101RT
				Engine 272:		AP18.00-P-0101RTC
US S	Service 4		every 2 years:			
			Check bodywork for paint work damage by service advisor			AP98.00-P-9850RT
			Underside of vehicle			
			Chassis and load-bearing body components: Check for damage and corrosion by service advisor			AP00.20-P-0090RT
			Engine compartment			
			Replace brake fluid			AP42.00-P-4280RT
US S	Service 5		every 26,000 mi or 2 years:			
			Passenger compartment			
			Replace combination filter			AP83.00-P-8384RT
US Serv	vice 6 and	7	not applicable			

Completed ⊠ ↓		N	lot OK ↓
US Service 8	every 52,000 mi or 4 years:		
	Engine compartment		
	Replace engine air-cleaner insert	Engine 113:	AP09.10-P-0980RT
		Engine 272:	AP09.10-P-0980RTC
US Service 9	not applicable		
US Service 10	every 13,000 mi or 1 year:		
	Panorama sliding roof: Clean and lubricate guide mechanism		AP77.20-P-7732RT
US Service 11	every 65,000 mi or 5 years:		
	Passenger compartment		
	Replace fuel filter		AP47.20-P-0780RT
US Service 12 Engine 113	every 91,000 mi or 5 years: Engine compartment		
	Replace spark plugs		AP15.10-P-1580RT
US Service 12 Engine 272	every 78,000 mi or 5 years: Engine compartment		
	Replace spark plugs		AP15.10-P-1580RTC
US Service 13	every 143,000 mi or 15 years:		
	Engine compartment		
	Replace coolant	Engine 113:	AP20.00-P-2080RT
		Engine 272:	AP20.00-P-2080RTC
US Service 14-19	not applicable		
US Service 20	once at 39,000 mi:		
	Underside of vehicle		
	Automatic transmission - oil and filter change		AP27.00-P-2702W

	Completed \boxtimes		Not OK	
	↓		↓	
		Vehicle over 143,000 mi:		
		Check if all fluid levels and changes are updated		
F≆AP		Transmission		
F≆AP		Rear axle		
⊯AP		Front axle		
F≆AP		Transfer case		
		Check if air, fuel, ventilation filters are updated		
FAP		Engine air filter		
FAP		Fuel filter		
F≆AP		Combination filter		
		Check integrity of engine, mechanical comonents		
¥AP		Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ		
⊯AP		Perform leak down test (hot and cold)		AP00.20-P-0053RT
F≆AP		Check spark plugs		
F≆AP		Exhaust system hangers and leaks		
		Check damaged / worn drivetrain parts		
FAP		Front wheel bearing play		
β≆AP		Rear wheel bearing play		
β≆AP		Axles joint play		
FAP		Flexible discs		
⊯ AP		Tie rod and drag link joints		