

AP00.20-U-1208VAC SERVICE SHEET for Mercedes-Benz Maintenance System (USA) 20.4.06

MODEL 171 AMG models only

Passenger cars Model Year 2007



Customer:		Repair order number:		
First visit	at 1,000 - 3,000 miles	Performed	YES NO	
Tire Rotation (non staggered width wheel setup only)	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES NO	
Tire Inspection (staggered and non- staggered width wheel setup)	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES NO	
Current mileage reading:			:	
Service work to be performed as advised by Completion date: Confirm work has been performed by sig service advisor: below:			k has been performed by signing	

i

US Service 4 through US Service 20 apply to "Additional work" items only.

Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2.

Perform each service as described.

US Service		first at 10,000 mi or 1 year;	after first every 20,000 mi or 2 years	
1	US Service	first at 20,000 mi or 2 years;	after first every 20,000 mi or 2 years Not OK	
↓	_ ↓		↓	
		Engine compartment		
	0	Leakage - Major components Check for chafe marks, line routing, damaged components i In the event of leakage, determine cause and perform repair via separate work order		AP00.20-P-0053V
	0	Check catch, safety catch and hinges on engine hood for proper operation.		AP88.40-P-8851V
	0	Battery, check and correct fluid level. Check battery condition using "Midtronics MCR 717" Tester. Attach Midtronics MCR 717 Test Report print out here.		AP54.10-U-5453A
	0	Check condition of poly-V-belt		AP13.22-P-1351VT
		Check fluid level, correct as required \boxed{i} If there is a loss of fluid, determine cause and perform repair via separate work order		
	0	Brake system		AP42.10-P-4210V
	0	Power steering		AP46.00-P-4611V
	0	Windshield washer system (incl. summer/winter cleanser)		AP82.35-P-8210N
600		Interior		
	0	Reset service indicator in instrument cluster		AP00.20-P-0042V
		Function check		
	0	Horn		
	0	Warning/indicator lamps, illumination and interior lighting		AP54.30-P-5452C
	0	Windshield wipers, windshield washer system, headlamp cleaning system		AP82.30-P-8252V
	0	Check seat belts and buckles for signs of external damage and proper function		AP91.40-P-9150V
	0	Check parking brake (function test only)		AP42.00-P-4290V
		Wheels, brakes		
Ť	Ť 0	Remove and install wheels		AP40.10-P-4050V
		Check front brake pads for lining thickness (remove right front wheel)		AP42.10-P-4251V
	0	Check front/rear brake pads for lining thickness		AP42.10-P-4251V
	0	Check condition/thickness of front/rear brake discs		AP42.10-P-4251V

US Service	US Serv			No	t OK	
1 ↓		2 ↓			↓	
		Ŏ	Inspect tires for damage and splits, m re tread depth, record in mm:	neasu-	•	AP40.10-P-4051Z
			LF RF LR outside	RR		
			inside			
		0	Correct tire inflation pressure and enter bar or psi.	ter in		
			LF RF LR bar/psi:	RR		
			Underside of vehicle			
↑ '	†	0	Leakage - Major components Check for chafe marks, line routing, diged components in the event of leakage, determine se and perform repair via separate we der	e cau-		AP00.20-P-0053V
		0	Check front axle ball joints for play, cl rubber boots	check		AP33.20-P-3353V
		0	Inspect condition of driveshaft flexible discs	le		AP41.10-P-4152V
		0	Inspect play of tie rod and and drag li joints, inspect rubber boots	ink		AP46.00-P-4653V
60			Trunk			
		0	Check trunk lighting			
	201		Vehicle front/rear			
		0	Check wiper blade condition			AP82.30-P-8253G
		0	Check and correct headlamp setting			AP82.10-P-8260V
Co	mpleted	√		N	ot OK ↓	
US Ser	rvice 3		every 10,000 mi or 1 year:			
			Engine compartment			
			Engine - oil and filter change			AP18.00-P-0101VT
US Ser	rvice 4		every 2 years:			
			Check bodywork for paint work dama by service advisor	age		AP98.00-P-9850BA
			Underside of vehicle			
			Chassis and load-bearing body components: Check for damage and corrosion by service advisor			AP00.20-P-0090BA
			Engine compartment			
			Replace brake fluid			AP42.00-P-4280V
US Ser	rvice 5		every 30,000 mi or 2 years:			
			Passenger compartment			
			Replace combination filter			AP83.00-P-8384V

Completed ⊠			Not OK	
↓			<u></u>	
US Service 6 and 7	not applicable			
US Service 8	every 40,000 mi or 4 years:			
	Engine compartment			
	Replace engine air-cleaner insert			AP09.10-P-0980VT
US Service 9 and 10	not applicable			
US Service 11	every 150,000 mi or 15 years:			
	Trunk			
	Replace fuel filter			AP47.20-P-0780Q
US Service 12	every 100,000 mi or 5 years:			
	Engine compartment			
	Replace spark plugs			AP15.10-P-1580VT
US Service 13	every 150,000 mi or 15 years:			
	Engine compartment			
	Replace coolant			AP20.00-P-2080VT
US Service 14-19	not applicable			
US Service 20	once at 40,000 mi			
	Underside of vehicle			
	Automatic transmission - oil and filter			AP27.00-P-2702W
Commissed 🔽	change	V	Not OK	
Completed ⊠ ↓	Perfor	m: Yes ↓	Not OK ↓	
·	Vehicle over 150,000 mi:		v	
	Check if all fluid levels and changes are u	p-		
	dated	•		
F AP □	Transmission			
F AP □	Rear axle			
	Check if air, fuel, ventilation filters are u)-		
⊯AP □	Engine air filter			
⊯AP □	Fuel filter			
 ₩FAP	Combination filter			
	Check integrity of engine, mechanical co			
⊯ AP □	Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ			
 ⊯FAP □	Perform leak down test (hot and cold)			AP00.20-P-0053V
 ⊯°AP □	Check spark plugs			
— I≆AP □	Exhaust system hangers and leaks			
_	Check damaged / worn drivetrain parts		_	
 ⊯SAP □	Front wheel bearing play			
— I≆AP □	Rear wheel bearing play			
— I≆AP □	Axle joint play			
FAP □	Driveshaft flexible discs	_	_	
F AP □	Tie rod and drag link joints			