

Service

AP00.20-U-1208FA

Service Sheet for Mercedes-Benz Maintenance System (USA)

15.03.04

AMG models only MODEL 203

Passenger Cars Model Year 2005

USA



Customer:		Repair order number:				
First visit	at 1,000 - 3,000 miles	;	Performed	YES	NO	
Tire Rotation (non-staggered width wheel setup only)	Performed in accorda manufacturer's recom		Tires rotated	YES	NO	
Tire Inspection (staggered and non- staggered width wheel setup)	Inspect tires for dama tire inflation pressure	ige and correct	Tires inspected	YES	NO	
Current mileage reading: _		(Oil grade/viscosity: _			
Additional notes:						
	0 miles or 1 year, then 0 miles or 2 years, the	•	-			
Determine "Additional	l work" needed, if any.	Refer to "Addit	ional Work" secti	on		
(check if applicable) once at first service at:	10,000 mi or 1 year		every:	2 years		
at approx. every:	60,000 mi			150,000 mi		
	50,000 mi or 4 years			Spark plugs		
	60,000 mi or 5 years					
	150,000 mi or 15 years					
i See last page for "Add Additional flat rates ap	ditional work". oply for procedures marked	d with 🎜 🖉 AP				
'4-203AMG-05A (03/04)		Mercedes-Benz USA, LLC		Reproduction or translation in	whole or in part is not p	

P-2374-203AMG-05A (03/0 Dealer Workshop Services www.MBUSA.com

Mercedes-Benz USA, LLC

Reproduction or translation in whole or in part is not permitted without written authorization from the publisher. 1-1800-FOR-MERCedes

completed	× ↓	A-Service	□↓	O ↓	B-Service	Not O.ł ↓	۲.
		Vehicle passenger compartment					
		Function check					
		Warning/indicator lamps, illumination and interior lighting	\mathbf{X}	\otimes			
		Windshield wipers, windshield washer system	X	\otimes			AP82.35-P-8252BA
		Headlamp cleaning system	X	\otimes			
		Check seat belts for damage and proper function		\otimes			AP91.40-P-9150P
		Reset maintenance counter in instrument cluster	X	\otimes			
		At every service interval: Panoramic sliding roof - clean and lubricate guide mechanism	X	8			AP77.20-P-7732PB
		Replace dust filter		\otimes			AP83.00-P-8381P
		Check parking brake (function test only)		\otimes			AP42.00-P-4290BA
		Wheels, brakes					
		Check front brake pads for lining thickness (remove 1 front wheel at "A" service)	X				AP42.10-P-4251BP
		Check brake pad thickness (front and rear)		\otimes			AP42.10-P-4251BP
		Check condition of brake discs (front and rear)		\otimes			AP42.10-P-4251BP
		Inspect tires for damage and condition	X	\otimes			AP40.10-P-4051Z
		Correct tire inflation pressure	X	\otimes			
		Measure tread depth, enter in mm: LF RF LR RR outside		8			AP40.10-P-4051Z
		center inside					

completed	× ↓	A-Service	□	O B-Service ↓	Not O.⊮ ↓	۲.
		Vehicle under body Visual inspection for leaks: Leakage - Major components Chafe marks, line routing, components. In the event of leakage, determine cau- se and perform repair via separate work order.		8		AP00.20-P-0053BA
		Check condition of front axle ball joints and rubber boots		\otimes		AP33.20-P-3353BP
		Check condition of steering's mechanical components and rubber boots		8		AP46.00-P-4653F
		Engine compartment				
		Visually check: Leakage - Major components Chafe marks, line routing, components. In the event of leakage, determine cau- se and perform repair via separate work order.		8		AP00.20-P-0053BA
		Engine oil and filter change Check and correct fluid level	X	\otimes		AP18.00-P-0101AE
		Brake system	X	\otimes		AP42.10-P-4210Z
		Power steering		× ×		AP46.00-P-4611P
		Windshield washer	X	8		AP82.35-P-8210P
		Check condition of poly-V-belt		8		AP13.22-P-1351Z
		Battery Check battery condition using "Midtronics MCR 717" Tester	\boxtimes	8		AP54.10-U-5453A
		Check catch, safety catch and hinges of engine hood for proper operation. Replace components with even the slightest malfunction.		8		
	_	Trunk	_		_	
		Correct tire inflation pressure in spare tire	\mathbf{X}	\otimes		

		Additional Work	~		
complet	edi⊠i	Perform:	Yes ↓	Not O.I ↓	ς.
		Once at first service at 10,000 mi or 1 year:			
i≈ AP		Parking brake - Adjust cable slack			AP42.20-P-4262P
		At approx. every 60,000 mi:			
IF AP		Check condition of driveshafts flex discs			AP41.10-P-4152Z
		At approx. every 50,000 mi or 4 years:			
I≊ AP		Replace air cleaner filter element			
		At approx. every 60,000 mi or 5 years:			
IF AP		Replace fuel filter			AP47.20-P-0780PV
IF AP		Replace activated charcoal filter			AP83.00-P-8382P
i≉ AP		Sliding/pop-up roof: clean sliding rails and sliders			AP77.20-P-7731A
		Every 2 years:			
IF AP		Replace brake fluid			AP42.00-P-4280BP
r≆ AP		Check body for paint damage by service Advisor			AP98.00-P-9850BA
i≊ AP		Check chassis and supporting body parts for damage and corrision by Service Advisor			AP00.20-P-0090BA
		At approx. every 150,000 mi or 15 years:			
I≉ AP		Replace coolant			AP20.00-P-2080A
		Replace spark plugs			
I≊ AP		At approx. every 100,000 mi or 5 years:			AP15.10-P-1580A

completed	ı ⊠ †	Perform:	Yes ↓	Not O.K. ↓
		Vehicle over 150,000 mi:		
		Check if all fluid levels and changes are updated		
i≉ AP		Transmission		
IF AP		Rear axle		
I≉ AP		Front axle (if applicable)		
r≉ AP		Transfer case (if applicable)		
		Check if air, fuel, ventilation filters are updated		
i≉ AP		Engine air filter		
i≉ Ap		Fuel filter		
I≉ AP		Combination / dust filter (if applicable)		
r≉ AP		Activated charcoal filter (if applicable)		
		Check integrity of engine, mechanical components		
i≉ AP		Perform compression test (hot and cold)		BE01.00-Z-999AZ
IF≆ AP		Perform leak down test (hot and cold)		AP00.20-P-0053GH
r≓ AP		Check spark plugs		
i≉ AP		Exhaust system hangers and leaks		
		Check damaged / worn drivetrain parts		
IF≆ AP		Front wheel bearings play		
if Ap		Rear wheel bearings play		
IF≆ AP		Axles joints play		
i≉ AP		Flexible discs		
IF AP		Tie rod and drag link joints		