

**MODEL 220**  
except AMG models and S600

**Passenger cars Model Year 2006**  
USA

**Model 220**



Customer: \_\_\_\_\_

Repair order number: \_\_\_\_\_

First visit at 1,000 - 3,000 miles Performed YES  NO

Tire Rotation (non staggered width wheel setup only) Performed in accordance with the tire manufacturer's recommended intervals Tires rotated YES  NO

Tire Inspection (staggered and non-staggered width wheel setup) Inspect tires for damage and correct tire inflation pressure Tires inspected YES  NO

Current mileage reading: \_\_\_\_\_

Oil grade/viscosity: \_\_\_\_\_

Additional notes: \_\_\_\_\_

Service work to be performed as advised by service advisor:

Completion date:

Confirm work has been performed by signing below:




1st A service at 13,000 miles or 1 year, then every 26,000 miles or 2 years






1st B service at 26,000 miles or 2 years, then every 26,000 miles or 2 years











Determine "Additional Work" needed, if any. Refer to "Additional work section" (check if applicable)

at approx. every:	52,000 mi or 4 years	<input type="checkbox"/>	every:	2 years	<input type="checkbox"/>
	52,000 mi or 5 years	<input type="checkbox"/>		5 years	<input type="checkbox"/>
	65,000 mi or 5 years	<input type="checkbox"/>		Spark Plugs	<input type="checkbox"/>
	143,000 mi or 15 years	<input type="checkbox"/>	once at:	39,000 mi	<input type="checkbox"/>
				143,000 mi	<input type="checkbox"/>

**i** See last page for "Additional Work".  
Additional flat rates apply for procedures marked with **AP**

Completed <input checked="" type="checkbox"/>	A-Service <input type="checkbox"/>	<input type="radio"/> B-Service	Not OK																				
↓	↓	↓	↓																				
	<b>Interior</b>																						
<input type="checkbox"/> Reset maintenance counter in instrument cluster	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	AP00.20-P-0042M																				
<input type="checkbox"/> Replace combination/dust filter (if equipped)		<input checked="" type="radio"/>	AP83.00-P-8381MA																				
<b>Function check</b>																							
<input type="checkbox"/> Horn, high beam flasher, hazard warning flashers, turn signals	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	<input type="checkbox"/>																				
<input type="checkbox"/> Warning/indicator lamps, illumination and interior lighting	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	<input type="checkbox"/>																				
<input type="checkbox"/> Front and rear lamps	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	<input type="checkbox"/>																				
<input type="checkbox"/> Windshield wipers, windshield washer system	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	<input type="checkbox"/> AP82.35-P-8252BA																				
<input type="checkbox"/> Headlamp cleaning system	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	<input type="checkbox"/>																				
<input type="checkbox"/> Check seat belts for damage and proper function		<input checked="" type="radio"/>	<input type="checkbox"/> AP91.40-P-9150M																				
<input type="checkbox"/> Check parking brake (function test only)		<input checked="" type="radio"/>	<input type="checkbox"/> AP42.00-P-4290BA																				
	<b>Wheels, brakes</b>																						
<input type="checkbox"/> Remove and mount wheels		<input checked="" type="radio"/>	<input type="checkbox"/> AP40.10-P-4050Z																				
<input type="checkbox"/> Check front brake pad lining thickness (remove 1 front wheel)	<input checked="" type="checkbox"/>		<input type="checkbox"/> AP42.10-P-4251I																				
<input type="checkbox"/> Check brake pads for lining thickness front/rear		<input checked="" type="radio"/>	<input type="checkbox"/> AP42.10-P-4251I																				
<input type="checkbox"/> Check condition/thickness of brake discs front/rear		<input checked="" type="radio"/>	<input type="checkbox"/> AP42.10-P-4251I																				
<input type="checkbox"/> Check tires for damage and condition	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	<input type="checkbox"/> AP40.10-P-4051Z																				
<input type="checkbox"/> Measure tread depth, enter in mm:		<input checked="" type="radio"/>	<input type="checkbox"/> AP40.10-P-4051Z																				
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"></td> <td style="width: 12.5%; text-align: center;">LF</td> <td style="width: 12.5%; text-align: center;">RF</td> <td style="width: 12.5%; text-align: center;">LR</td> <td style="width: 12.5%; text-align: center;">RR</td> </tr> <tr> <td style="padding-left: 5px;">outside</td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> </tr> <tr> <td style="padding-left: 5px;">center</td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> </tr> <tr> <td style="padding-left: 5px;">inside</td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> <td style="border-bottom: 1px solid black; width: 40px;"></td> </tr> </table>		LF	RF	LR	RR	outside					center					inside							
	LF	RF	LR	RR																			
outside																							
center																							
inside																							
<input type="checkbox"/> Correct tire inflation pressure	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	<input type="checkbox"/>																				
	<b>Underside of vehicle</b>																						
<input type="checkbox"/> <b>Leakage - Major components</b> Check for chafe marks, line routing, damaged components <input type="checkbox"/> In the event of leakage, determine cause and perform repair via separate work order		<input checked="" type="radio"/>	<input type="checkbox"/> AP00.20-P-0053BA																				
<input type="checkbox"/> Check condition of front axle ball joints and rubber boots		<input checked="" type="radio"/>	<input type="checkbox"/> AP33.20-P-3353BA																				
<input type="checkbox"/> Check condition of steering mechanical components and rubber boots		<input checked="" type="radio"/>	<input type="checkbox"/> AP46.00-P-4653F																				

Completed <input checked="" type="checkbox"/>	A-Service <input type="checkbox"/>	B-Service <input type="checkbox"/>	Not OK
↓	↓	↓	↓
 <b>Engine compartment</b>			
<input type="checkbox"/> <b>Leakage - Major components</b> Check for chafe marks, line routing, damaged components <i>i</i> In the event of leakage, determine cause and perform repair via separate work order	⊗		<input type="checkbox"/> AP00.20-P-0053BA
<input type="checkbox"/> Check condition of poly-V-belt	⊗		<input type="checkbox"/> AP13.22-P-1351Z
<input type="checkbox"/> Check catch, safety catch and hinges on engine hood for proper operation.	⊗	⊗	<input type="checkbox"/> AP88.40-P-8851M
<input type="checkbox"/> Engine oil and filter change	⊗	⊗	<input type="checkbox"/>
Engine 113			AP18.00-P-0101AF
Engine 112			AP18.00-P-0101AE
<b>Check fluid level, correct as required</b> <i>i</i> If there is a loss of fluid, determine cause and perform repair via separate work order			
<input type="checkbox"/> Brake system	⊗	⊗	<input type="checkbox"/> AP42.10-P-4210Z
<input type="checkbox"/> Power steering	⊗		<input type="checkbox"/>
with Active Body Control Code 487a			AP46.00-P-4611N
without Active Body Control Code 487a			AP46.00-P-4611BB
<input type="checkbox"/> Active Body Control	⊗		<input type="checkbox"/> AP32.50-P-3213I
<input type="checkbox"/> Windshield washer system (incl. summer/winter cleanser)	⊗	⊗	AP82.35-P-8210N
 <b>Vehicle front/rear</b>			
<input type="checkbox"/> Check wiper blade condition	⊗	⊗	<input type="checkbox"/> AP82.30-P-8253G
<input type="checkbox"/> Check and correct headlamp setting	⊗		<input type="checkbox"/> AP82.10-P-8260M
 <b>Trunk</b>			
<input type="checkbox"/> Correct tire inflation pressure in spare tire	⊗	⊗	<input type="checkbox"/>
<input type="checkbox"/> Check trunk lighting	⊗	⊗	<input type="checkbox"/>
<input type="checkbox"/> Battery, check battery condition using "Midtronics MCR 717" tester	⊗	⊗	<input type="checkbox"/> AP54.10-U-5453A
<b>Additional Work</b>			
Completed <input checked="" type="checkbox"/>	Perform:	Yes	Not OK
↓		↓	↓
<b>Once at 39,000 mi:</b>			
 <input type="checkbox"/> Automatic transmission - oil and filter change		<input type="checkbox"/>	
Transmission 722.9			AP27.00-P-2702W
Transmission 722.6			AP27.00-P-2702I
 <input type="checkbox"/> Transfer case - oil change (4MATIC models)		<input type="checkbox"/>	AP28.00-P-2801P

Completed <input checked="" type="checkbox"/>	Perform:	Yes	Not OK
↓		↓	↓
<b>At approx. every 52,000 mi or 4 years:</b>			
 AP	<input type="checkbox"/> Check condition of driveshaft flex disks	<input type="checkbox"/>	<input type="checkbox"/> AP41.10-P-4152Z
 AP	<input type="checkbox"/> Replace air cleaner filter element	<input type="checkbox"/>	
<b>At approx. every 52,000 mi or 5 years:</b>			
 AP	<input type="checkbox"/> Replace activated charcoal filter (if equipped)	<input type="checkbox"/>	AP83.00-P-8382M
<b>At approx. every 65,000 mi or 5 years:</b>			
 AP	<input type="checkbox"/> Replace fuel filter	<input type="checkbox"/>	AP47.20-P-0780DC
<b>At approx. every 143,000 mi or 15 years:</b>			
 AP	<input type="checkbox"/> Replace coolant (water/anticorrosion/antifreeze mixture)	<input type="checkbox"/>	AP20.00-P-2080DA
<b>Replace spark plugs:</b>			
Engine 112, 113			
 AP	<input type="checkbox"/> <b>At approx every 91,000 mi or 5 years:</b>	<input type="checkbox"/>	AP15.10-P-1580AB
<b>Every 2 years:</b>			
 AP	<input type="checkbox"/> Replace brake fluid	<input type="checkbox"/>	AP42.00-P-4280BA
 AP	<input type="checkbox"/> Check body for paint damage <b>by service advisor</b>	<input type="checkbox"/>	<input type="checkbox"/> AP98.00-P-9850BA
 AP	<input type="checkbox"/> Check chassis and supporting body parts for damage and corrosion <b>by service advisor</b>	<input type="checkbox"/>	<input type="checkbox"/> AP00.20-P-0090BA
<b>Every 5 years:</b>			
 AP	<input type="checkbox"/> Tilt/sliding roof: clean sliding rails and sliders	<input type="checkbox"/>	<input type="checkbox"/> AP77.20-P-7731A

	Completed <input checked="" type="checkbox"/>	Perform:	Yes	Not OK
	↓		↓	↓
	<b>Vehicle over 143,000 mi:</b>			
	<b>Check if all fluid levels and changes are updated</b>			
AP	<input type="checkbox"/>	Transmission	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Rear axle	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Front axle (if applicable)	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Transfer case (if applicable)	<input type="checkbox"/>	<input type="checkbox"/>
	<b>Check if air, fuel, ventilation filters are updated</b>			
AP	<input type="checkbox"/>	Engine air filter	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Fuel filter	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Combination / dust filter (if applicable)	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Activated charcoal filter (if applicable)	<input type="checkbox"/>	<input type="checkbox"/>
	<b>Check integrity of engine, mechanical components</b>			
AP	<input type="checkbox"/>	Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Perform leak down test (hot and cold)	<input type="checkbox"/>	<input type="checkbox"/> AP00.20-P-0053BA
AP	<input type="checkbox"/>	Check spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Exhaust system hangers and leaks	<input type="checkbox"/>	<input type="checkbox"/>
	<b>Check damaged / worn drivetrain parts</b>			
AP	<input type="checkbox"/>	Front wheel bearing play	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Rear wheel bearing play	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Axle joint play	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Flexible discs	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/>	Tie rod and drag link joints	<input type="checkbox"/>	<input type="checkbox"/>