

AP00.20-U-0001C SERVICE SHEET FOR Flexible Service System (FSS) 25.9.97

MODEL 170 as of M.Y. 1998 with FSS

Passenger Cars MY 1998 to MY 2001

System is also known as "Active Service System (ASSYST)" in the Workshop Information System (WIS)

Model 170



Cu	stomer:	Repair order num	ber:
	ork has been by signing below	Initial Service Or Typ	pe of service last performed
Technician:		B	A
	Determine need for type	e of service:	→
	Please define type of service t	to be performed here!	Please note:
	Current	odometer reading:	An A-Service must always be
	B-Service last perform	ned at mi/km:e's intial service)	followed by a B-Service
	Difference	in mi/km:	
		Difference < 14,000 mi 22,000 km Difference ≥ 14 22	,000 mi 2 000 km B-Service
	g need for A-Service or B-s	service: st "R-Service" is less (<) than 14.000 miles/22 000 km (as d	etermined from Service Booklet or dealer

If the distance driven since the last "B-Service" is less (<) than 14,000 miles/22 000 km (as determined from Service Booklet or dealer records), an "A-Service" should be performed.

If the distance driven since the last "B-Service" is **greater** (≥) than 14,000 miles/22 000 km (as determined from Service Booklet or dealer records), a "B-Service" should be performed.

Special flat rates apply for procedures marked with FAP

Determine "Additional work" needed, if any: (check if applicable) 1 See last page for "Additional work"							
at approx every:	30,000 mi / 48,000 km or 4 years		every:	2 years			
	60,000 mi / 96,000 km or 4 years			3 years			
	60,000 mi / 96,000 km or 5 years			Spark Plugs			

complete	ed ⊠ ↓ □	Brake test on dynamometer or test drive. Check parking brake and run in according to specifications (on vehicles with 4MATIC, ASR, ETS, ESP observe instructions in Maintenance Manual!). Enter brake values in N: front rear Parking brake left Parking	\Box \rightarrow	→ B-Service→⊗	Not O.K. ↓	AP42.00-P-4290BA
		Vehicle passenger compartment				
		Function check				
		Horn, headlamp flasher, hazard flashers, turn signals	\boxtimes	\otimes		
		Warning/indicator lamps, illumination and interior lighting	\boxtimes	\otimes		
		Exterior lighting incl. headlamps	\boxtimes	\otimes		
		Windshield wipers	\boxtimes	\otimes		AP82.35-P-8252BA
		Windshield washer	\boxtimes	\otimes		AP82.35-P-8252BA
		Headlamp cleaning system	\boxtimes	\otimes		
		Check seat belts for damage and proper function	\boxtimes	\otimes		AP91.40-P-9150Z
		Reset FSS counter in instrument cluster	\boxtimes	\otimes		
		Replace dust filter	\boxtimes	8		AP83.00-P-8381G
		Wheels, brakes				· .
		Remove and reinstall wheels, rotate if necessary, does not apply for vehicles with different tire sizes front/rear		\otimes		AP40.10-P-4050Z
		Check brake pads for lining thickness front/rear		\otimes		AP42.10-P-4251BA
		Check condition of brake discs front and rear		\otimes		AP42.10-P-4251BA
		Check thickness of brake pads by removing and reinstalling right front wheel	X			AP42.10-P-4251BA
		Check condition of brake discs by removing and reinstalling right front wheel	X			AP42.10-P-4251BA
		Check tires for damage and condition	\boxtimes	\otimes		AP40.10-P-4051Z
,		Measure tread depth, enter in mm	\boxtimes	\otimes		AP40.10-P-4051Z
	_	LF RF LR RR outside	[2]	~	_	
		Correct tire inflation pressure	\times	\otimes		

completed ⊠ I		A-Service	<u> </u>	O B-Service	Not O.K.	
	V	Vehicle underbody	↓	↓	V	
		vernice underbody				
		Visual check for Leakage - Major components Chafe marks, line routing, components. In the event of leakage, determine cause and perform repair via separate work order.		⊗		AP00.00-P-0053BA
		Check condition of front axle ball joints		\otimes		AP33.20-P-3353BA
		Check condition of steering's mechanical components		\otimes		AP46.00-P-4650BA
		Engine compartment				
		Visually check Leakage - Major components Chafe marks, line routing, components. In the event of leakage, determine cause and perform repair via separate work order.		⊗		AP00.00-P-0053BA
		Engine oil and filter change	\boxtimes	\otimes		AP18.00-P-0101AB
		Check and correct fluid level				
		Engine cooling system, antifreeze and corrosion protection°C	X	⊗		AP20.00-P-2010Z
		Brake system	\boxtimes	\otimes		AP42.10-P-4210Z
		Power steering		\otimes		AP46.00-P-4611BB
		If so equipped: Battery, wet cell Check acid level, replenish	×	⊗		AP54.10-P-5410A
		Additionally, check battery condition using "Midtronics MCR 717" Tester	\boxtimes	\otimes		SI54.10-P-0003A
		If so equipped: Battery, AGM/VRLA with black housing Check battery condition using "Midtronics MCR 717" Tester	\boxtimes	⊗		SI54.10-P-0003A
		A/C system refrigerant level		\otimes		AP83.00-P-8312DA
		In the event of leakage, determine cause and perform repair via separate work order.				
		Windshield washer	\boxtimes	\otimes		AP82.35-P-8210Z
		Check condition of poly-V-belt		\otimes		AP13.22-P-1351Z
		Lubricate throttle linkage, check function and condition		\otimes		AP30.10-P-3022ZA
		Lubricate catch, safety catch and hinges on engine hood.	\boxtimes	\otimes		AP88.40-P-8821BA

160		Front, rear of vehicle				
		Replace windshield wiper rubber inserts		\otimes		AP82.30-P-8280Z
		Inspect headlamp setting, adjust to correct setting		\otimes		AP82.10-P-8260A
6		Trunk				
		Check fluid level of soft top/hard top hydraulic system, roll bar, correct		\otimes		AP77.37-P-7710BA
		Additional Work				namental Auto-Patro Patro
	completed 🗵	Perform:	yes		Not O.K.	
	\		†		1	
		At approx. every 30,000 mi/48,000 km or 4 years:				
₩AP		Check condition of drive shaft flex discs				AP41.10-P-4152Z
₽₽AP		Retighten locking bolts for steering. Observe torque.				AP46.20-P-4671BA
		At approx. every 60,000 mi/96,000 km or 4 years:				
₩AP		Replace fuel filter (up to M.Y. 1999)				AP47.20-P-0780DB
₩AP		Replace air cleaner filter element				
₩₽AP		Check condition of fuel filler nozzle seal in filler neck, replace if damaged			·	AP47.10-P-4751A
		At approx. every 60,000 mi/96,000 km or 5 years:				
₽AP		Replace fuel filter (as of M.Y. 2000)				AP47.20-P-0780DB
		Every 2 years				
₽¥AP		Replace brake fluid				AP42.00-P-4280BA
₽¥AP		Inspect body for paint damage by Service Advisor				AP98.00-P-9850BA
₽AP		Check chassis and supporting body parts for damage and corrosion by Service Advisor				AP00.00-P-0090BA
		Every 3 years				
⊯ AP		Replace coolant				AP20.00-P-2080A
		Replace spark plugs				
		At approx. every 30,000 mi/50,000 km				
		or 4 years: Engine 111 (up to M.Y. 2000)				AP15.10-P-1580CA
		At approx. every 100,000 mi/160,000 km or 5 years:				
		Engine 111 (as of M.Y. 2001)				AP15.10-P-1580CA
		Engine 112 (as of M.Y. 2001)				AP15.10-P-1580A