Mercedes-Benz

AP00.20-U-1208DAC SERVICE SHEET for Mercedes-Benz Maintenance System (USA)

Model 211

MODEL 211

AMG and diesel models only

Passenger cars Model Year 2007

USA

Customer:		Repair order number:			
First visit	at 1,000 - 3,000 miles	Performed	YES NO		
Tire Rotation (non staggered width wheel setup only)	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES NO		
Tire Inspection (staggered and non- staggered width wheel setup)	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES NO		
Current mileage reading:		Oil grade/viscosity:	:		
Additional notes:					
Service work to be performed service advisor:	l as advised by Completion date:	Confirm work has been performed by signing below:			

i

US Service 1-11 and 15-20 apply to "Additional work" items only.

Vehicle determines need for US Service 12 (Engine oil and filter change) as well as US Service 13 or US Service 14 Perform each service as described.

Complete	d⊠ ↓			Not OK ↓	
US Service 1	¥	not applicable		¥	
US Service 2		every 40,000 mi or 4 years: Engine compartment			
		Replace engine air-cleaner insert	Engine 156:		AP09.10-P-0980TM
			Engine 642:		AP09.10-P-0980TI
US Service 3		every 30,000 mi or 2 years:			
		Engine compartment			
		Replace combination filter			AP83.00-P-8384T
US Service 4		not applicable			
US Service 5 Engine 156		every 150,000 mi or 15 years: Passenger compartment			
		Replace fuel filter			AP47.20-P-0780TC
US Service 5 Engine 642		every 20,000 mi or 2 years: Engine compartment			
		Replace fuel filter			AP47.20-P-0780TI
US Service 6		not applicable			
US Service 7 Engine 156		every 60,000 mi or 5 years: Engine compartment			
		Replace spark plugs			AP15.10-P-1580TM
US Service 8		every 150,000 mi or 15 years:			
		Engine compartment			
		Replace coolant	Engine 156:		AP20.00-P-2080DA
			Engine 642:		AP20.00-P-2080BA
US Service 9		every 2 years:			
		Check body for paint damage by service advisor			AP98.00-P-9850BA
		Engine compartment			
		Replace brake fluid			AP42.00-P-4280T
		Underside of vehicle			
		Chassis and load-bearing body compo- nents: Check for damage and corrosion by service advisor			AP00.20-P-0090BA
US Service 10		every 5 years:			
		Interior			
		Tilt/sliding roof: Clean slide rails and slide shoes			AP77.20-P-7731A
US Service 11		every 3 years:			
		Interior			
		Panorama sliding roof: Clean and lubricate guide mechanism			AP77.20-P-7732PB
US Service 12		every 10,000 mi or 1 year:			
	3	Engine compartment			
		Engine oil and filter change	Engine 156:		AP18.00-P-0101TM
			Engine 642		AP18.00-P-0101TI

US Service		first at 10,000 mi or 1 year;	after first every 20,000 mi or 2 years		
13	US Service	first at 20.000 mi or 2 years:	after first every 20,000 mi or 2 years		
	14	·····	Not		
	\downarrow			↓	
		Engine compartment			
	0	Leakage - Major components Check for chafe marks, line routing, dama- ged components i In the event of leakage, determine cau- se and perform repair via separate work or- der			AP00.20-P-0053BA
	0	Inspect poly-V-belt for damage			
	0	Check catch, safety catch and hinges on en- gine hood for proper operation.			AP88.40-P-8851T
		Check fluid level, correct as required i If there is a loss of fluid, determine cau- se and perform repair via separate work or- der			
	0	Brake system			AP42.10-P-4210Z
	0	Power steering	Engine 156:		AP46.00-P-4611BB
			Engine 642:		AP46.00-P-4611P
	0	Windshield washer system (incl. summer/winter cleanser)			AP82.35-P-8210N
	, D	Interior			
	0	Reset service indicator in instrument cluster			AP00.20-P-0042TA
		Function test			
	0	Warning/indicator lamps, illumination and interior lighting			
	0	Audible warning system			AP54.30-P-5450A
	0	Windshield washer system, incl. rear wind- ow washer (where applicable), headlamp cleaning system			AP82.30-P-8252T
	0	Check safety belts and buckles for signs of external damage and function			AP91.40-P-9150M
	0	Check parking brake (function test only)			AP42.00-P-4290R
Ģ		Wheels, brakes			
	I	Check condition/thickness of front brake pads/discs (remove right front wheel)			AP42.10-P-4251R
	0	Remove and install wheels			AP40.10-P-4050Z
	0	Check condition/thickness of brake pads/discs front/rear			AP42.10-P-4251R
	0	Inspect tires for damage and splits, measu- re tread depth, enter in mm: LF RF LR RR outside			AP40.10-P-4051Z
	0	inside Correct tire inflation pressure and enter in bar or psi. LF RF LR RR bar/psi:			

	US Service			Not OK	
13	14 ↓			\downarrow	
, v	D	Underside of vehicle			
T	0	Leakage - Major components Check for chafe marks, line routing, dama- ged components iIn the event of leakage, determine cau- se and perform repair via separate work or- der			AP00.20-P-0053BA
	0	Check front axle ball joints for play, check rubber boots			AP33.20-P-3353BA
	0	Inspect condition of driveshaft flexible discs			AP41.10-P-4152Z
	0	Inspect play of tie rod and drag link joints, inspect rubber boots			AP46.00-P-4653F
6		Trunk			
	0	Check trunk lighting			
	0	Check battery condition using "Midtronics MCR 717" Tester. Attach Midtronics MCR 717 Test Report print out here.			AP54.10-U-5453A
	0	Check TIREFIT sealant expiration date and enter here If necessary replace TIREFIT subject to a se- parate repair order (AMG wagons with third row seat only)			AP40.10-P-4054R
id		Vehicle front/rear			
	0	Check, correct headlamp setting			AP82.10-P-8260T
	0	Check wiper blade condition			AP82.30-P-8253G
C	ompleted 🗵			Not OK	
	↓ ·			\downarrow	
	ice 15 - 19 rvice 20	not applicable once at 40,000 mi:			
03 36	I VICE 20	Underside of vehicle			
		Automatic transmission - Oil and filter			AP27.00-P-2702W
Co	mpleted 🗵	change Perform:	Yes	Not OK	
	\downarrow		\downarrow	\downarrow	
		Vehicle over 150,000 mi: Check if all fluid levels and changes are up-			
	_	dated	_	_	
₩ ° AP		Transmission			
₩ĨAP		Rear axle Check if air, fuel, ventilation filters are up-			
		dated	-	-	
₩ AP		Engine air filter			
₩ AP		Fuel filter Combination filter			
₩Â₽					

	Completed 🗵	Perform:	Yes	Not OK	
	\downarrow		\downarrow	\downarrow	
		Check integrity of engine, mechanical co- monents			
₩AP		Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ			
₩ĨAP		Perform leak down test (hot and cold)			AP00.20-P-0053BA
₩ĨAP		Check spark plugs			
₩P		Exhaust system hangers and leaks			
		Check damaged / worn drivetrain parts			
₩ĨAP		Front wheel bearing play			
₩P		Rear wheel bearing play			
₩°AP		Axles joint play			
₩AP		Driveshaft flexible discs			
₩°AP		Tie rod and drag link joints			